



NOSE ASSEMBLY DATA SHEET



WHEN MOUNTING ON RIVETER:

Press & Hold in direction shown.



*USE ADAPTER 745751 WITH 745158 STROKE LIMITER



11/16 REV 9/25

GAGE BILT

MADE IN U.S.A.

44766 Centre Court Clinton Twp. MI 48038 USA
Ph: +1 (586) 226-1500 Fax: +1 (586) 226-1505
solutions1@gagebilt.com / www.gagebilt.com

Type:		Fasteners:	Recommended Tool: GB713
Single Action 1/4" Ø		MAGNA-GRIP®, MULTI-GRIP, MAXLOK® LOCKBOLTS	Alternate Tools: GB722 *GB745
Ref. No.	Qty.	Description	MG08-713-58RA
1	1	Anvil Insert	18848
2	1	Anvil & Holder Assy. (Inc. #1)	13525
3	1	Collet	28847
4	1	Super Grip Jaw Assembly	30860-S3
5	1	Spacer	60835
6	1	Frame	70864
7	1	Collet Bolt	70839
8	12	Link	70841
9	1	Lever	70843
10	6	Link Pin	70842
11	2	Set Screw	70844
12	2	Pivot Pin Assembly	70845
13	1	Bellcrank	70846
14	1	Drawbolt	70847
15	1	Anvil Adapter Assembly	70868
16	1	Extension-Collet	70875

MOUNTING INSTRUCTIONS

Attach riveter to air source for correct piston positioning. Push the drawbolt assembly forward (see above), before mounting. While holding drawbolt in a forward position, thread the nose assembly onto the riveter, making sure that both internal and external threads are connected. Use the jam-nut to lock the pulling head in position. Cycle the tool to make sure it is functional.

DISASSEMBLY AND ASSEMBLY

Disassembly:

Loosen and remove holder (2) from frame assy (6). Unscrew collet (3) which contains jaws (4), and spacer (5) from collet bolt (7).

Remove 2 set screws (11) and push out two pivot pins (12) to permit removal of linkage. Remove link pin (10) from Collet bolt (7) and links (8) to disengage from lever (9).

Remove five link pins (10) to disassemble lever (9), links (8), bellcrank (13) and drawbolt (14).

Reassembly:

Reverse the procedure. Linkage, consisting of lever (9), links (8), bellcrank (13) and drawbolt (14) should be assembled as a subassembly before inserting lever (9) into collet bolt (7). MAKE SURE NOTCHES ON COLLET BOLT (7) ARE POINTING TOWARDS LEVER (9). This complete subassembly may then be inserted into frame (6) and retained by pivot pins (12).